PIN CONFIGURATIONS

The PIN arrangement of BW3010T is shown in Figure 1.

```
         VSS ⊏ 1      16 ⊐ VDD
         OSC ⊏ 2      15 ⊐ REM
          S0 ⊏ 3      14 ⊐ CCS
          S1 ⊏ 4      13 ⊐ S10
          S2 ⊏ 5      12 ⊐ S9
          S3 ⊏ 6      11 ⊐ S8
          S4 ⊏ 7      10 ⊐ S7
          S5 ⊏ 8       9 ⊐ S6
```

In Figure 1, PIN REM can be used as output terminal which sends out the remote control code; PIN S0 to S10 are I/O terminals for key-board scanning; PIN CCS is input terminal for user_code select through connect with S0-S10. PIN osc are used for crystal oscillator.